

# COMPUTER NETWORKS LAB

Roll No: 19p0012 Name: Aitzaz Tahir Ch

Section: Bs(CS)-5B

Lab No: 1



#### **Ipconfig**

# ipconfig/all

```
C:\Users\Aitzaz Tahir Ch>ipconfig/all
Windows IP Configuration
  Host Name . . . . . . . . : DESKTOP-2BVRQ7U
  Primary Dns Suffix . . . . . :
  Node Type . . . . . . . . : Hybrid
  IP Routing Enabled. . . . . . : No
  WINS Proxy Enabled. . . . . . : No
Ethernet adapter Ethernet:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
  Description . . . . . . . . : Realtek PCIe GbE Family Controller
  Physical Address. . . . . . . : 98-FA-9B-D5-A4-47
  DHCP Enabled. . . . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Local Area Connection* 9:
  Media State . . . . . . . : Media disconnected

Connection-specific DNS Suffix . :

Description . . . . . . : Microsoft Wi-Fi Direct Virtual Adapter
  Physical Address. . . . . . : 08-71-90-EB-35-C6 DHCP Enabled. . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Local Area Connection* 10:
  Media State . . . . . . .
                               . . . : Media disconnected
  Connection-specific DNS Suffix .:
  Description . . . . . . . . : Microsoft Wi-Fi Direct Virtual Adapter #2
  Physical Address. . . . . . . : 0A-71-90-EB-35-C5
  DHCP Enabled. . . . . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Wi-Fi:
```

```
Wireless LAN adapter Wi-Fi:
  Connection-specific DNS Suffix .:
  Description . . . . . . . . : Intel(R) Wireless-AC 9560 160MHz
  Physical Address. . . . . . . : 08-71-90-EB-35-C5
  DHCP Enabled. . . . . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
  Link-local IPv6 Address . . . . : fe80::c13e:df5a:7ca2:99f2%10(Preferred)
  IPv4 Address. . . . . . . . . : 192.168.1.116(Preferred)
  Lease Obtained. . . . . . . : Sunday, September 12, 2021 6:01:13 AM
  Lease Expires . . . . . . . : Thursday, September 16, 2021 4:22:09 PM
  Default Gateway . . . . . . : 192.168.1.1
  DHCP Server . . . . . . . . . : 192.168.1.1
  DHCPv6 IAID . . . . . . . . . : 151548304
  DHCPv6 Client DUID. . . . . . . : 00-01-00-01-28-59-BC-8D-98-FA-9B-D5-A4-47
  DNS Servers . . . . . . . . . : 192.168.1.1
  NetBIOS over Tcpip. . . . . . : Enabled
C:\Users\Aitzaz Tahir Ch>
```

## ipconfig/release

```
C:\Users\Aitzaz Tahir Ch>ipconfig/release
Windows IP Configuration
No operation can be performed on Ethernet while it has its media disconnected.
No operation can be \mathsf{performed} on Local Area Connection^* 9 while it has its \mathsf{media} disconnected.
No operation can be performed on Local Area Connection* 10 while it has its media disconnected.
Ethernet adapter Ethernet:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix . :
Wireless LAN adapter Local Area Connection* 9:
  Media State . . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Local Area Connection* 10:
  Media State . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Wi-Fi:
  Connection-specific DNS Suffix .:
  Link-local IPv6 Address . . . . : fe80::c13e:df5a:7ca2:99f2%10
  Default Gateway . . . . . . . :
C:\Users\Aitzaz Tahir Ch>
```

### ipconfig/release6

```
C:\Users\Aitzaz Tahir Ch>ipconfig/release6
Windows IP Configuration
No operation can be performed on Ethernet while it has its media disconnected.
No operation can be performed on Local Area Connection* 9 while it has its media disconnected.
No operation can be performed on Local Area Connection* 10 while it has its media disconnected.
Ethernet adapter Ethernet:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Local Area Connection* 9:
                   . . . . . . . . : Media disconnected
  Media State . .
  Connection-specific DNS Suffix .:
Wireless LAN adapter Local Area Connection* 10:
  Media State . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
Wireless LAN adapter Wi-Fi:
  Connection-specific DNS Suffix .:
  Link-local IPv6 Address . . . . : fe80::c13e:df5a:7ca2:99f2%10
  IPv4 Address. . . . . . . . . : 192.168.1.116
  Subnet Mask . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . : 192.168.1.1
C:\Users\Aitzaz Tahir Ch>
```

#### ipconfig/renew

```
C:\Users\Aitzaz Tahir Ch>ipconfig/renew
Windows IP Configuration
No operation can be performed on Ethernet while it has its media disconnected.
No operation can be performed on Local Area Connection* 9 while it has its media disconnected.
No operation can be performed on Local Area Connection* 10 while it has its media disconnected.
Ethernet adapter Ethernet:
  Media State . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
Wireless LAN adapter Local Area Connection* 9:
  Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
Wireless LAN adapter Local Area Connection* 10:
   Media State . . . . . . . . : Media disconnected
   Connection-specific DNS Suffix .:
Wireless LAN adapter Wi-Fi:
   Connection-specific DNS Suffix .:
   Link-local IPv6 Address . . . . : fe80::c13e:df5a:7ca2:99f2%10
   IPv4 Address. . . . . . . . . : 192.168.1.116
   Subnet Mask . . . . . . . . . : 255.255.255.0
   Default Gateway . . . . . . . : 192.168.1.1
 \llsans\Aitzaz Tahin Ch
```

### ipconfig/renew6

```
C:\Users\Aitzaz Tahir Ch>ipconfig/renew6
Windows IP Configuration
No operation can be performed on Ethernet while it has its media disconnected.
No operation can be performed on Local Area Connection^st 9 while it has its media disconnected.
No operation can be performed on Local Area Connection* 10 while it has its media disconnected.
An error occurred while renewing interface Wi-Fi : The semaphore timeout period has expired.
Ethernet adapter Ethernet:
                    . . . . . . . : Media disconnected
  Media State . . .
  Connection-specific DNS Suffix .:
Wireless LAN adapter Local Area Connection* 9:
  Media State . . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Local Area Connection* 10:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Wi-Fi:
  Connection-specific DNS Suffix .:
  Link-local IPv6 Address . . . . : fe80::c13e:df5a:7ca2:99f2%10
  IPv4 Address. . . . . . . . . : 192.168.1.116
  Subnet Mask . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . : 192.168.1.1
C:\Users\Aitzaz Tahir Ch>
```

### ipconfig /all | findstr /v 00-00-00 | findstr Physical

```
C:\Users\Aitzaz Tahir Ch>ipconfig /all | findstr /v 00-00-00 | findstr Physical Physical Address. . . . . . . : 98-FA-9B-D5-A4-47
Physical Address. . . . . . . : 08-71-90-EB-35-C6
Physical Address. . . . . . . : 0A-71-90-EB-35-C5
Physical Address. . . . . . . : 08-71-90-EB-35-C5
C:\Users\Aitzaz Tahir Ch>
```

#### ipconfig /all | findstr IPv4

```
C:\Users\Aitzaz Tahir Ch>ipconfig /all | findstr IPv4
IPv4 Address. . . . . . . . . . : 192.168.1.116(Preferred)
C:\Users\Aitzaz Tahir Ch>
```

### ipconfig /displaydns

#### ipconfig/flushdns

```
C:\Users\Aitzaz Tahir Ch>ipconfig/flushdns
Windows IP Configuration
Successfully flushed the DNS Resolver Cache.
C:\Users\Aitzaz Tahir Ch>
```

# ipconfig /?

```
C:\Users\Aitzaz Tahir Ch>ipconfig /?
   ipconfig [/allcompartments] [/? | /all |
                                 /renew [adapter] | /release [adapter] |
                                 /renew6 [adapter] | /release6 [adapter] |
                                 /flushdns | /displaydns | /registerdns |
/showclassid adapter |
                                 /setclassid adapter [classid] |
                                 /showclassid6 adapter |
                                 /setclassid6 adapter [classid] ]
where
                        Connection name
   adapter
                       (wildcard characters * and ? allowed, see examples)
   Options:
                        Display this help message
       /all
                        Display full configuration information.
      /release
                        Release the IPv4 address for the specified adapter.
       /release6
                        Release the IPv6 address for the specified adapter.
      /renew
                        Renew the IPv4 address for the specified adapter.
                        Renew the IPv6 address for the specified adapter.
       /renew6
                        Purges the DNS Resolver cache.
      /flushdns
       /registerdns
                        Refreshes all DHCP leases and re-registers DNS names
                        Display the contents of the DNS Resolver Cache.
      /displaydns
                        Displays all the dhcp class IDs allowed for adapter.
       /showclassid
      /setclassid
                        Modifies the dhcp class id.
                        Displays all the IPv6 DHCP class IDs allowed for adapter.
       /showclassid6
       /setclassid6
                        Modifies the IPv6 DHCP class id.
The default is to display only the IP address, subnet mask and
default gateway for each adapter bound to TCP/IP.
For Release and Renew, if no adapter name is specified, then the IP address
leases for all adapters bound to TCP/IP will be released or renewed.
For Setclassid and Setclassid6, if no ClassId is specified, then the ClassId is removed.
Examples:
   > ipconfig
                                     ... Show information
    > ipconfig /all
                                     ... Show detailed information
                                     ... renew all adapters
   > ipconfig /renew
    > ipconfig /renew EL*
                                     ... renew any connection that has its
                                         name starting with EL
                                     ... release all matching connections,
   > ipconfig /release *Con*
```

### ipconfig /all >D:\ipconfig-results.txt

```
C:\Users\Aitzaz Tahir Ch>ipconfig /all >D:\ipconfig-results.txt
C:\Users\Aitzaz Tahir Ch>
```

```
ipconfig-results - Notepad
File Edit Format View Help
Windows IP Configuration
  Host Name . . . . . . . . . : DESKTOP-2BVRQ7U
  Primary Dns Suffix ....:
  Node Type . . . . . . . . . : Hybrid
  IP Routing Enabled. . . . . . : No
  WINS Proxy Enabled. . . . . . : No
Ethernet adapter Ethernet:
  Media State . . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
  Description . . . . . . . . . . Realtek PCIe GbE Family Controller
  DHCP Enabled. . . . . . . . . . Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Local Area Connection* 9:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
  Description . . . . . . . . . . . . Microsoft Wi-Fi Direct Virtual Adapter
  Physical Address. . . . . . . : 08-71-90-EB-35-C6
  DHCP Enabled. . . . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Local Area Connection* 10:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
  Description . . . . . . . . : Microsoft Wi-Fi Direct Virtual Adapter #2
  Physical Address. . . . . . . : 0A-71-90-EB-35-C5
  DHCP Enabled. . . . . . . . . . Yes
  Autoconfiguration Enabled . . . . : Yes
Wireless LAN adapter Wi-Fi:
  Connection-specific DNS Suffix .:
  Description . . . . . . . . : Intel(R) Wireless-AC 9560 160MHz
  Physical Address. . . . . . . : 08-71-90-EB-35-C5
  DHCP Enabled. . . . . . . . : Yes
```

<

# nslookup google.com

C:\Users\Aitzaz Tahir Ch>nslookup google.com

Server: UnKnown

Address: 192.168.1.1

Non-authoritative answer:

Name: google.com

Addresses: 2a00:1450:4019:801::200e

142.250.181.14

C:\Users\Aitzaz Tahir Ch>

# nslookup 142.250.181.14

C:\Users\Aitzaz Tahir Ch>nslookup 142.250.181.14

Server: UnKnown

Address: 192.168.1.1

Name: fjr04s05-in-f14.1e100.net

Address: 142.250.181.14

C:\Users\Aitzaz Tahir Ch>